


- ① BORE A HOLE OF DIAMETER 20mm LESS THAN THE WIDTH OF POST.  
HOLE TO BE BORED THROUGH 150mm THICK DLC LAYER & UPTO BOTTOM OF 150mm THICK GSB LAYER (TOTAL DEPTH OF HOLE = 820mm)
- ② RE-FILL THE BORE HOLE COMPLETELY WITH THE EXCAVATED SOIL WITH ADEQUATE TAMPING & RAMMING IN LAYERS NOT EXCEEDING 150mm.
- Ⓐ REFER FIGURE-2



**FIGURE-1 :- FIRST STEP**